



Locate the two cross legs



Assemble as shown



Remove the screws

Locate the inner pipe



Remove the Height Adjustment Control Collar



Pull up the inner pipe



Extend Fully



Line up holes
on outer pipe
with cross legs





Replace all
4 screws and
tighten

Slide base
cover on
as shown



Replace
Height Adjustment
Collar and
Tighten as Shown






Place Motor Head onto Inner Pipe and Tighten Set Knob. (make sure the set knob is loosened enough to slide on)

Remove Grill Nut




Place Real Grill onto Fan Motor and Line Up with the 3 Positioning Knobs



Replace the Grill Nut and
Tighten



Place the Fan Blade over the motor shaft and make
sure to line the up the notch with the
notch on the blade push it
back firmly






Place the blade
cap on the shaft
and screw it
counterclockwise
snug
do not over-
tighten

open all the grill
fastening clips



Hang the front safety grill on back grill as shown



A close-up photograph of a white plastic mesh grill, likely from a dehydrator or food processor. The grill is composed of a grid of small, diamond-shaped openings. A white plastic clip is attached to the right edge of the grill. The background is a solid, dark brown color.

Close all the
grill clips
your done